

## **Baby Corner Edge Protectors Installation Instructions:**

\*Kindly read through before starting the installation process.

This is an Adult Only installation process.\*

**NB: BEFORE INSTALLING ALLOW THE EDGE GUARD TO HANG OUT ON THE WASHING LINE (IN THE SUN) FOR 4-5 HOURS OR ROLL IT THE OTHER WAY AND PLACE BETWEEN TWO HEAVY OBJECTS (This is to straighten the edge guard somewhat so that it doesn't curl up when you stick it down and pull lose from the surface)**

1. Ensure your child is being supervised by an informed caregiver.
2. Clean areas with alcohol swabs provided, ensuring the area is completely dry before you apply the product.
3. Wipe the surface with the Self-Adhesive Promoter - Used to prepare the surface for adhesives, speeds up the curing time and strengthens the bond.
4. Use Alcohol swabs to clean the inner part of the protectors BEFORE sticking the self-adhesive tape to the product.
- 5. Stick the adhesive tape to the product NOT the surface.**
6. Stick the corners down first, then measure the edge guard before cutting it to size.
7. Use a measuring tape to measure the length of the EDGE GUARD.
8. Remove film from double sided tape.
9. Place the corners and edge guard on the dangerous areas and corners and position into place.
10. Rub down vigorously, making sure there are no air bubbles underneath.
11. Allow 12 hours for the self adhesive to set properly.
- 12. Make sure you clean up afterwards, discard all packaging, alcohol swabs and the adhesive promoter.**